

Associated Paint, Inc.



17-600.01

Deluxe Interior Flat Wall Paint Data Sheet

<u>Characteristics:</u>	<u>Specifications</u>	<u>Surface Preparation</u>
<p>17-600 is an economy vinyl acrylic flat finish suitable for interior use. 17-600 goes on easily and dries to a uniform, flat finish. 17-600 offers good hiding and touch-up. Especially good for areas requiring constant maintenance and repainting.</p> <p>Vehicle Type: Vinyl Acrylic</p> <p>FINISH: Flat</p> <p>RECOMMENDED USES:</p> <ul style="list-style-type: none"> • Interior Drywall • Plaster • Primed Metal • Wood <p>TINTING: 17-600 may be tinted to light and medium tints with universal colorants.</p> <p>THINNING: Not recommended. However if thinning is necessary for spray application, add no more than ½ pint of water per gallon.</p> <p>DRYING TIME, @ 77° F, 50% RH: Temperature & Humidity Dependent</p> <p>Touch: 30 minutes Recoat: 2 to 3 hours Flash Point: N/A</p> <p>VOC: < 100 g/l</p> <p>Weight Solids: 46.1 ± 2% Volume Solids: 26.4 ± 2% Weight Per Gallon: 11.2 Lbs</p>	<p>COVERAGE: 17-617 will cover up to 350 to 400 sq.ft @ 3.0 mils wet, 1.0 mils dry</p> <p>APPLICATION: Apply 17-600 by brush, roller or airless spray (1800-2000 PSI and .017 tip).</p> <p style="text-align: center;"><u>Cleanup Information</u></p> <p>Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral sprits.</p> <p style="text-align: center;"><u>Surface Preparation</u></p> <p>Warning! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse affects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.</p>	<p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Wood Sand any exposed wood to a fresh surface. Patch all holes and imperfections with a wood filler or putty and sand smooth. Prime with 44-500 or 45-500W</p> <p>Mildew Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the mildewed area for 10 minutes. Rinse thoroughly with water and allow the surface to dry prior to painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach water solution.</p> <p>Caulking Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p> <p>Drywall Fill cracks and holes with patching paste / spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.</p>