

# Associated Paint, Inc.



## 80-520.01 Super Prep R-35 Primer Data Sheet

<u>Characteristics:</u>	<u>Specifications</u>	<u>Surface Preparation</u>
<p>Super Prep is a styrene acrylic emulsion adhesive, formulated to provide a firm base for the adhesion of vinyl wall coverings. Super Prep provides a tie coat over a multitude of substrates such as drywall, plaster, wallpaper, etc. Super Prep provides a permanently tacky base suitable for hanging heavy duty vinyl wall coverings.</p> <p><b>Vehicle Type:</b> Styrene Acrylic</p> <p><b>FINISH:</b> Low Sheen</p> <p><b>RECOMMENDED USES:</b></p> <ul style="list-style-type: none"> <li>• Interior Drywall</li> <li>• Plaster</li> </ul> <p><b>TINTING:</b> Not Recommended</p> <p><b>THINNING:</b> Not recommended.</p> <p><b>DRYING TIME, @ 77° F, 50% RH:</b> Temperature &amp; Humidity Dependent</p> <p><b>Touch:</b> 30 minutes <b>Recoat:</b> 2 hours <b>Flash Point:</b> N/A</p> <p><b>VOC:</b> &lt; 100 g/l</p> <p><b>Weight Solids:</b> 24.7 ± 2% <b>Volume Solids:</b> 21.8 ± 2% <b>Weight Per Gallon:</b> 8.56 Lbs</p>	<p><b>COVERAGE:</b> 80-520 will cover up to 400 sq.ft @ 4.0 mils wet, 1.0 mils dry</p> <p><b>APPLICATION:</b> Apply 80-520 by brush, roller or airless spray (1800-2400 PSI and .017).</p> <p style="text-align: center;"><b><u>Cleanup Information</u></b></p> <p>Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral sprits.</p> <p style="text-align: center;"><b><u>Surface Preparation</u></b></p> <p><b>Warning!</b> Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse affects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.</p>	<p><b>Plaster</b> Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p><b>Mildew</b> Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the mildewed area for 10 minutes. Rinse thoroughly with water and allow the surface to dry prior to painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach water solution.</p> <p><b>Caulking</b> Gaps between walls, ceilings, crown moldings, and other interior trim can be filled with the appropriate caulk after priming the surface.</p> <p><b>Drywall</b> Fill cracks and holes with patching paste / spackle and sand smooth. Joint compounds must be cured and sanded smooth. Remove all sanding dust.</p>