

Associated Paint, Inc.



600 Blue, 601 White Bond-It Data Sheet

<u>Characteristics:</u>	<u>Specifications</u>	<u>Surface Preparation</u>
<p>Bond-It is a masonry bonding adhesive and fortifying add mixture for concrete and plaster. Bonds new concrete and plaster to old. Permanently bonds Thin-set, stucco and plasters to concrete, cinder block, stone, brick, concrete slabs, tile, plywood, sheet rock, rock lathe, hardboard, etc. Bond-It may be used as an admixture to mortar to increase resiliency and tensile strength.</p> <p>Vehicle Type: Acrylic</p> <p>FINISH: Slight Gloss</p> <p>RECOMMENDED USES:</p> <ul style="list-style-type: none"> • Concrete • Thin-set Mortar • Plaster • Admixture for Concrete <p>TINTING: None</p> <p>THINNING: Not recommended.</p> <p>DRYING TIME, @ 77° F, 50% RH: Temperature & Humidity Dependent</p> <p>Touch: 20 minutes Recoat: 1 hours Flash Point: N/A</p> <p>VOC: < 100 g/l</p> <p>Weight Solids: 53 % ± 2% Volume Solids: 47 % ± 2% Weight Per Gallon: 9.0 Lbs</p>	<p>COVERAGE: Bond-It will cover up to 300 sq.ft</p> <p>APPLICATION: Apply Bond-It by brush, roller or airless spray (1800-2400 PSI and .017).</p> <p>Cleanup Information</p> <p>Clean spills and spatters immediately with soap and warm water. Clean hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with mineral spirits to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using mineral sprits.</p> <p>Surface Preparation</p> <p>Warning! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse affects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at 1-800-424-LEAD (in US) or contact your local health authority.</p>	<p>Plaster Bare plaster must be cured and hard. Textured, soft, porous, or powdery plaster should be treated with a solution of 1 pint household vinegar to 1 gallon of water. Repeat until the surface is hard, rinse with clear water and allow to dry.</p> <p>Mildew Remove before painting by washing with a solution of 1 part liquid bleach and 3 parts water. Apply the solution and scrub the mildewed area. Allow the solution to remain on the mildewed area for 10 minutes. Rinse thoroughly with water and allow the surface to dry prior to painting. Wear protective eyewear, waterproof gloves, and protective clothing. Quickly wash off any mixture that comes in contact with your skin. Do not add detergents or ammonia to the bleach water solution.</p> <p>Masonry, Concrete, Cement, Block All new surfaces must be cured according to the supplier's recommendations usually about 30 days. Remove all form release and curing agents. Rough surfaces can be filled to provide a smooth surface. If painting cannot wait 30 days, allow the surface to cure 7 days and prime the surface with (41-600 Acrylic Pigmented Masonry Sealer)</p>