

Associated Paint, Inc.



11-35.01

Wet-Look Super High Solids Clear Sealer Data Sheet

<u>Characteristics:</u>	<u>Specifications</u>	<u>Surface Preparation</u>
<p>Wet Look Super Hi-Solids is a water clear, solvent based sealer designed to protect and beautify concrete floors, and interlocking brick. Wet Look Super Hi-Solids is formulated for the professional with 100% Acrylic Resins. At 35% solids, Wet Look Super Hi-Solids is higher in solids than most conventional sealers. Wet Look Super Hi-Solids provides water and UV light resistance with unusually good adhesion to a variety of substrates.</p>	<p>COVERAGE: 11-35 will cover up to 250 sq.ft per gallon @ 2.0 mils wet, 1.0 mils dry</p> <p>APPLICATION: Apply 11-35 by brush, roller (short Nap Mohair) or low pressure airless spray.</p> <p>One coat is usually sufficient however if a second coat is desired, allow a minimum of 12 hours between coats.</p>	<p>Brick Pavers: Follow all instructions as noted above, paying particular attention to efflorescence. Make certain joints are filled with sand allowing minimum 1/4" recess between top of sand joint & top of brick.</p> <p>Steel Floated Concrete: To allow proper penetration of Wet-Look, concrete that is shiny smooth should be etched with 1 part muriatic acid to 3 parts water.</p>
<p>Vehicle Type: 100% Acrylic</p>	<p><u>Surface Preparation</u></p>	<p>*Chattahoochee, Exposed Aggregate: Wet Look Super Hi-Solids is excellent for concrete embedded stone surfaces, however because of possible softening of epoxy, Wet Look Super Hi-Solids is not recommended for epoxy bonded stone surfaces.</p>
<p>FINISH: Gloss</p>	<p>All surfaces to be coated must be clean and free of moisture, efflorescence, dirt, grease, oil, chalk, mildew and any other foreign matter.</p>	<p>Important Do's & Don'ts</p>
<p>RECOMMENDED USES:</p>	<ul style="list-style-type: none"> • Oils, Grease, Dirt: Scrub with TSP, detergent and/or a degreaser, rinse well & allow to dry. • Mildew & Algae: Apply a solution of 1 part bleach to 3 parts water, rinse well and allow to dry. • Efflorescence (salts): Apply a solution of 1 part muriatic acid to 3 parts water, rinse well allow to dry. 	<ul style="list-style-type: none"> • Surface must be dry for 24 hours before application! • Do not apply when temperature is below 50°F or above 90°F. • Do not apply if rain or heavy dew is threatening. • Do not thin. • Avoid heavy buildup and overlapping of sealer. • One coat is usually sufficient. However, if a second coat is desired, allow 12 hours between coats.
<p>TINTING: None</p>	<p>Sealed, painted or waxed surfaces: To allow proper penetration of Wet Look Super Hi-Solids, all sealers, paint, etc. should be removed prior to it's application. Wet Look Super Hi-Solids is designed for use on uncoated surfaces or over itself, however good results may be obtained when used over similar solvents (xylene, toluene thinned) acrylic type coatings/sealers. Before attempting to apply Wet Look Super Hi-Solids over existing coatings check for adhesion and compatibility by coating a small test area. If lifting, wrinkling, excessive bubbling, slow drying, or other undesirable conditions occur, the previous coating must be completely removed.</p>	<p><u>Cleanup Information</u></p>
<p>THINNING: Not recommended.</p>		<p>Clean spills, spatters, hands and tools immediately after use with xylene. Follow manufacturer's safety recommendations when using xylene.</p>
<p>DRYING TIME, @ 77° F, 50% RH: Temperature & Humidity Dependent</p>		<p>Warning! Sealed surfaces, particularly those sealed with High Solids sealers, may become slippery when wet. A Non-Skid additive product may be added to help reduce slipping.</p>
<p>Touch: 30 minutes</p>		
<p>Recoat: 12 hours</p>		
<p>Allow 72 hours dry time before heavy traffic.</p>		
<p>Flash Point: 80°F</p>		
<p>VOC: <650 g/l</p>		
<p>Weight Solids: 35%</p>		
<p>Volume Solids: 30%</p>		
<p>Weight Per Gallon: 7.8 Lbs.</p>		